

STRATLOCK RAIL SYSTEM

BY FASTMOUNT

Setting the standard for panel mounting

INSTALLATION GUIDE

SL-FB Stratlock® Range - Adhesive Fix

SL-FB



USE WITH:

SL-M10, SL-M18



INSTALL WITH:

Fastmount SuperGroove® Adhesive

INSTALLATION STEPS Adhesive fix method

<p>1 Push fit SL-FB into frame</p>	<p>2 Locate SL-FB into correct position</p>	<p>3 Engage SL-M18 two clicks into SL-FB</p>	<p>4 Apply Fastmount SuperGroove Adhesive CG-5010 to SL-M18</p>
<p>5 Press panel into place</p>	<p>6 Use panel support while adhesive dries</p>	<p>7 Once adhesive has dried, remove panel. Replace and engage only one click to adjust panel around the SL-M18's point</p>	<p>8 Once panel is in desired location, engage second click by pressing panel into its final position</p>

! NEW

Stratlock SL-RLE shown, available 2021

Creating and decorating aluminium framework has never been faster or more flexible. With only one profile required and adaptable connectors, the Stratlock Rail System is a foolproof way to create a consistent substrate for the perfect panel finish. For further information or technical support contact: info@fastmount.com

info@fastmount.com

www.fastmount.com

*Specification subject to change without notice, see website for updates.
INSTALLATION GUIDE SL-FB Adhesive Fix/ 10/21 Copyright © Fastmount Ltd.



PROUDLY DESIGNED IN NEW ZEALAND